

# STANDARD CAGE (W) 1.5M X (L) 2.4M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

3	13MM X 1.5M ALUMINIUM TUBE
4	13MM X 1.2M ALUMINIUM TUBE
6	16MM UPRIGHTS
4	JOINER CORNER & 2 TEES (OR 6 BUILD A BALLS)

## IF ORDERED WITH COVER

1	COVER
14	STEEL PEGS
12	13MM CLIPS
12	16MM CLIPS

## ASSEMBLY PROCESS

**STEP 1:** The legs are made up of the larger tubes (16mm). Push a build a ball or joiner onto each one (refer to the cage diagram).

**STEP 2:** Use the 1.5m tubes as the width bars.

**STEP 3:** Connect the 1.2m + 1.2m tube with 1 tee joiner between them to create the 2.4m length bars.

**STEP 4:** Push the legs (16mm uprights) into the ground to create your erected height (refer to the height table).

**STEP 5:** Lay cover (if ordered) over the frame and secure using the 16mm clips on each leg, and equally spacing the 13mm clips on the crossbars. Bury the ends of the cover and secure with pegs.

Please Note: If due heavy forecast of snow please remove the roof netting beforehand.)

HEIGHT TABLE		
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL
1.2M	1.5M	300MM
900MM	1.2M	300MM
700MM	900MM	200MM
500MM	600MM	100MM

