

# PEA & BEAN FRAME

## (H) 1.8M X (L) 2M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

### CONTENTS

5	ALUMINIUM TUBING 2M
4	UPRIGHT TUBE CLIP
1	COVER
20	PIPE CLIPS 19MM
8	STEEL PEGS

### ASSEMBLY PROCESS

**STEP 1:** Insert the tube clips into 4 of the 19mm x 2m poles

**STEP 2:** Insert two 2m poles into the ground on an angle creating an A shape, repeat this twice around a poles width apart.

**STEP 3:** With the last pole lay across the top of the A shapes, this will fit into upright tube clips of the A-frames and secure in place.

**STEP 4:** Push the complete frame into the ground at least 300mm for stability.

**STEP 5:** Lay the Jute Netting over the frame and trim/bury any excess. Secure the netting to the poles with the 19mm Pipe Clips, and steel pegs to secure the netting to the soil which is provided.

