STANDARD CAGE (W) 1.5M X (L) 5.4M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

	13MM X 900MM ALUMINIUM TUBE	
10	13MM X 900MM ALUMINIUM EXTENSION TUBE	
4	13MM X 600MM ALUMINIUM TUBE	
8	16MM UPRIGHTS	
4	JOINER CORNER & 4 TEES (OR 8 BUILD A BALLS)	

ASSEMBLY PROCESS

STEP 1: The legs are made up of the larger tubes (16mm). Push a build a ball or joiner onto each one (refer to the cage diagram).

STEP 2: Connect the 600mm + 900mm extension pole to create the 1.5m width bars.

STEP 3: Connect the 900mm + 900mm extension tube to create the 1.8m length bars. Connect the 1.8m + 1.8m + 1.8m tubes together with 2 tee joiners between them to create the 5.4m length bars.

STEP 4: Push the legs (16mm uprights) into the ground to create your erected height (refer to the height table).

STEP 5: Lay cover (if ordered) over the frame and secure using the 16mm clips on each leg, and equally spacing the 13mm clips on the crossbars. Bury the ends of the cover and secure with pegs.

1.5M =

600MM+

900MM

EXTENSION

Please Note: If due heavy forecast of snow please remove the roof netting beforehand.)

IF ORDERED WITH COVER

1	COVER
26	STEEL PEGS
16	13MM CLIPS
16	16MM CLIPS

HEIGHT TABLE				
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL		
1.2M	1.5M	300MM		
900MM	1.2M	300MM		
700MM	900MM	200MM		
500MM	600MM	100MM		

