

# STANDARD CAGE (W) 2.16M X (L) 3M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

6	13MM X 1.5M ALUMINIUM TUBE
6	13MM X 1.08M ALUMINIUM TUBE
9	16MM UPRIGHTS
4	JOINER CORNER & 4 TEES (OR 9 BUILD A BALLS)
1	JOINER CROSS

## IF ORDERED WITH COVER

1	COVER
20	STEEL PEGS
16	13MM CLIPS
16	16MM CLIPS

HEIGHT TABLE		
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL
1.2M	1.5M	300MM
900MM	1.2M	300MM
700MM	900MM	200MM
500MM	600MM	100MM

## ASSEMBLY PROCESS

**STEP 1:** The legs are made up of the larger tubes (16mm). Push a build a ball or joiner onto each one. When laying out the legs make sure the cross joiner or build a ball is in the center. (Refer to the cage diagram).

**STEP 2:** Connect the 1.08m + 1.08m tube with 1 tee joiner between them to create the 2.16m width bars.

**STEP 3:** Connect the 1.5m + 1.5m tube with 1 tee joiner between them to create the 3m length bars.

**STEP 4:** Connect each joiner tee to the center cross/crosses with the remaining tubes.

**STEP 5:** Push the legs (16mm uprights) into the ground to create your erected height (refer to the height table).

**STEP 6:** Lay cover (if ordered) over the frame and secure using the 16mm clips on each leg, and equally spacing the 13mm clips on the crossbars. Bury the ends of the cover and secure with pegs.

Please Note: If due heavy forecast of snow please remove the roof netting beforehand.)

