

PORTABLE DOMED CAGE (W) 1.2M X (L) 2.4M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

3	ALUMINIUM HOOP
8	ALUMINIUM TUBE 19MM X 1.2M
4	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
2	LARGE JOINER (FLAT TEE)

ASSEMBLY PROCESS BASE

STEP 1: Take 6 of the 1.2m poles and lay them out in a rectangle.

STEP 2: Connect the 4 joiners at all corners and 2 tees in the middle.

STEP 3: Place the hoops on top of the joiners and push in.

ASSEMBLY PROCESS CLOCHE SUPPORT BAR

STEP 1: Insert 2 x joiner upright tube clip to 2x 19mm x 1.2m poles.

STEP 2: Clip 1x support bar in between each hoop.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

