

# PORTABLE DOMED CAGE (W) 1.2M X (L) 3M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

3	ALUMINIUM HOOP
6	ALUMINIUM TUBE 19MM X 1.5M
2	ALUMINIUM TUBE 19MM X 1.2M
4	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
2	LARGE JOINER (FLAT TEE)

## ASSEMBLY PROCESS BASE

**STEP 1:** Take 4 of the 1.5m poles and 2 x 1.2m and lay them out into two rectangles.

**STEP 2:** Connect the 6 joiners (4 corners and 2 tees).

**STEP 3:** Place the hoops on top of the joiners and push in.

## ASSEMBLY PROCESS CLOCHE SUPPORT BAR

**STEP 1:** Insert 2x joiner upright tube clip to 2 x 1.5m poles, this creates the support bars.

**STEP 2:** Clip 1x support bar in between each hoop.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

