

PORTABLE HIGHTOP CAGE (W) 0.80M X (L) 1.2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

| | |
|---|--|
| 2 | ALUMINIUM HOOP |
| 3 | ALUMINIUM TUBE 19MM X 1.2M |
| 2 | ALUMINIUM TUBE 19MM X 800MM |
| 2 | LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP |
| 4 | LARGE JOINER (CORNER) |

ASSEMBLY PROCESS BASE

STEP 1: Take 2x 1.2m length bars, and 2x 800mm width bars and lay them out in a rectangle.

STEP 2: Connect the 4 joiners at all corners.

STEP 3: Place the hoops on top of the joiners and push in.

STEP 2: Clip 1x support bar in between the two hoops.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

ASSEMBLY PROCESS CLOCHE SUPPORT BAR

STEP 1: Insert 2x joiner upright tube clips to the remaining 1.2m tube at both ends.

