

# PORTABLE HIGHTOP CAGE (W) 0.80M X (L) 2.4M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

3	ALUMINIUM HOOP
6	ALUMINIUM TUBE 19MM X 1.2M
2	ALUMINIUM TUBE 19MM X 800MM
8	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
4	LARGE JOINER (CORNER)
2	LARGE JOINER (FLAT TEE)

1	COVER
12	BLACK HOOP CLIPS 19MM
16	U PINS

## ASSEMBLY PROCESS BASE

**STEP 1:** Take 4x 1.2m length bars, and 2x 800mm width bars and lay them out in a rectangle. Refer to diagram.

**STEP 2:** Connect the 4 joiner corners at the four corners and two tees in the middle.

**STEP 3:** Place the hoops on top of the joiners and push in.

**STEP 3:** Use pipe clips provided to secure your netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

## ASSEMBLY PROCESS CLOCHE SUPPORT BAR

**STEP 1:** Insert 4x joiner upright tube clips to the remaining 1.2m tubes at both ends.

**STEP 2:** Clip 2x support bars in between the two hoops.

