

LARGE HIGH TOP ALUMINIUM HOOP FRAME

(H) 1.8M X (W) 1.2M X (L) 1.5M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

| | |
|---|--------------------------------|
| 2 | ALUMINIUM HOOP |
| 4 | ALUMINIUM HOOP EXTENSION 800MM |
| 3 | ALUMINIUM TUBE 1.5M |
| 2 | ALUMINIUM TUBE 1.2M |
| 4 | JOINER CORNER |
| 2 | UPRIGHT TUBE CLIP |

ASSEMBLY PROCESS BASE

STEP 1: Take 2 of the 1.2m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, connect each corner with a joiner to complete the rectangle.

STEP 2: Insert the 800mm extension poles into the upright slots of the corners.

STEP 3: Insert the hoop width ways into the top of the uprights, repeat this at both ends.

STEP 4: To create the support bar use the last 1.5m tube and insert the upright tube clips at either end. Once created, place this in the center of the hoops, once between each hoop.

For a tight fit some pressure is required when fitting the clips, and joiners into the aluminium.

