

# SQUARE ALUMINIUM HOOP FRAME

(H) 1.73M X (W) 1.2M X (L) 1.5M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

|   |                                |
|---|--------------------------------|
| 2 | ALUMINIUM SQUARE HOOP          |
| 4 | ALUMINIUM HOOP EXTENSION 800MM |
| 4 | ALUMINIUM TUBE 1.5M            |
| 2 | ALUMINIUM TUBE 1.2M            |
| 4 | JOINER CORNER                  |
| 4 | UPRIGHT TUBE CLIP              |

## ASSEMBLY PROCESS

**STEP 1:** Take two of the 1.5m poles and lay them on the ground, then lay two of the 1.2m poles either side to create a rectangle.

**STEP 2:** Place the four corners on each corner making sure the joiner has a free slot pointing upwards.

**STEP 3:** Insert the four the 800mm hoop extensions into the free slots in the joiner corners. Then insert the square hoop into the extensions, this will complete either end.

**STEP 4:** To assemble the 2 cloche support bars insert the upright tube clips into either end of the last two 1.5m tubes. Once assembled fixed lengthways between the two hoops. Space equally apart.

