

# SMALL ALUMINIUM HOOP FRAME (H) 1.46M X (W) 1.2M X (L) 4.5M

## CONTENTS

4	ALUMINIUM SQUARE HOOP
8	ALUMINIUM HOOP EXTENSION 800MM
9	ALUMINIUM TUBE 1.5M
4	ALUMINIUM TUBE 1.2M
4	JOINER CORNER
4	JOINER TEE
6	UPRIGHT TUBE CLIP

## ASSEMBLY PROCESS

**STEP 1:** Take two of the 1.5m poles and lay them on the ground, then lay two of the 1.2m poles either side to create a rectangle. Repeat this three times two create three rectangles back to back.

**STEP 2:** Place the four corners on each corner making sure the joiner has a free slot pointing upwards. Place a tee joiner either side of the centre poles connecting the width poles to the length. Once again the tee joiners should have one slot free pointing upwards.

**STEP 3:** Insert the eight 800mm hoop extensions into the free slots in the joiner corners and tees. Then insert the round hoops into the extensions, this will complete the four hoops.

**STEP 4:** To assemble the three cloche support bars insert the upright tube clips into either end of the three 1.5m tubes. Once assembled fixed lengthways between the hoops. Space equally apart with one support bar per hoop.

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

