

HIGHTOP ALUMINIUM HOOP FRAME

(H) 1.68M X (W) 0.8M X (L) 6M

CONTENTS

5	ALUMINIUM HOOP
12	ALUMINIUM TUBE 1.5M
10	ALUMINIUM TUBE 1.2M
5	ALUMINIUM TUBE 800MM
4	JOINER TEE
6	JOINER CROSS
8	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS BASE

STEP 1: Take 2x 800mm width tubes and 2x 1.5m length tubes and create a rectangle. Repeat this four times to create four interconnecting rectangles on a flat surface. Connect each corner with a tee joiner and six crosses in the middle.

STEP 2: Insert a hoop onto each end of the frame and two in the middle making sure the joiners are fully submerged.

STEP 3: Connect the upright tube clips into each end of 8x 1.5m tubes to create the support bars, you can then connect these between the hoops.

STEP 4: (This part may require two people)
Mark on the floor where the legs of the cage are going

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

to go, then use a mallet and a piece of wood to sink the poles into the ground to reach the erected height of 0.9m. You can then lift the top part of the cage and connect it on top of the legs.

For a tight fit, some pressure is required when fitting the clips, and a mallet is recommended for submerging the joiners into the aluminium.

(Please note) if due heavy forecast of snow please remove the cover beforehand.

