

# SQUARE ALUMINIUM HOOP FRAME

(H) 1.85M X (W) 1.2M X (L) 1.2M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

2	ALUMINIUM HOOP
10	ALUMINIUM TUBE 1.2M
4	JOINER TEE
4	UPRIGHT TUBE CLIP

## ASSEMBLY PROCESS BASE

**STEP 1:** Take 4x 1.2m tubes and lay them out into a square on a flat surface and connect each corner with a tee joiner.

**STEP 2:** Insert a hoop onto each end of the frame making sure the joiners are fully submerged.

**STEP 3:** Connect the upright tube clips into each end of 2x 1.2m tubes to create the support bars, you can then connect these between the two hoops.

**STEP 4:** (This part may require two people)  
Mark on the floor where the legs of the cage are going to go, then use a mallet and a piece of wood to sink

the poles into the ground to reach the advised erected height. You can then lift the top part of the cage and connect it on top of the legs.

For a tight fit, some pressure is required when fitting the clips, and a mallet is recommended for submerging the joiners into the aluminium.

(Please note) if due heavy forecast of snow please remove the cover beforehand.

