



Installation Guide

The 3rd gen wifi camera can be mounted anyway you like as you can flip the video in the app so you can choose to skip to Step 2. However if you have the TV camera option the bracket must be flipped so the feed on the tv is the correct way up.

Step 1: First, remove the bracket and rotate it 180 degrees and re-attach it. This will allow you to tilt the camera further. To remove the bracket use the Allen key provided. Please refer to image "A".

Step 2: To get an idea of the placement of the camera. We generally recommend placing the camera opposite the entrance on the rear of the house. This will give you a clear view of the entrance. To make sure the camera is the correct way up make sure the small lens is on top of the large lens. You when you flip the house when finished it will then appear below the lens. Refer to image "A" for now.

Step 3: Line the bracket up with the vertical pole and thread the four cable ties around the horizontal poles and through the two holes on the bracket "not the centre hole". Make sure this is secure in place as it will be flipped upside down and will fall forward. Please refer to image "B".

Step 4: Before flipping, make sure to tighten the bracket with the Allen key, and position the camera so its facing the entrance. Please refer to image "C". You can then cut off the tails of the cable ties if you want a cleaner look.

Step 5: To tidy up the cables we recommend feeding them out and under the rear side of the house. Use a cable tie to tie to the outer rim stopping it moving and pulling the camera. Please refer to image "D".

Step 6: Download the app from the Qr code included with the box, or find the Greenfeathers App in the play or apple store and following the instructions for the app setup. For the tv camera option connect the 30m cable to the camera and follow the instructions.

