

PEA & BEAN DOMED FRAME (W) 750MM X (L) 1.5M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

| | |
|----|--|
| 5 | ALUMINIUM TUBING 19MM X 1.5M |
| 4 | ALUMINIUM TUBING 19MM X 1.2M |
| 2 | ALUMINIUM TUBING 19MM X 750MM |
| 6 | LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP |
| 2 | HIGH TOP HOOP - SMALL - SINGLE |
| 4 | LARGE JOINER TEE |
| 1 | COVER |
| 30 | 19MM CLIPS |
| 14 | STEEL PEGS |

ASSEMBLY PROCESS (BASE)

STEP 1 : Take 2 of the 19mm x 1.5m poles and 2 of the 750mm poles and lay them out in a rectangle.

STEP 2 : Connect the 4 joiners at both ends.

STEP 3 : Insert 4 of the 1.2m x 19mm poles (legs) into the joiners and then push them into the soil roughly 30cm.
This gives you the base.

STEP 4 : Place the hoops on top of the joiners and push in.

ASSEMBLY PROCESS (CLOCHE SUPPORT BAR)

STEP 1 : Insert 2 x joiner upright tube clips into both ends of the 3 remaining 1.5m poles, this creates the support bar.

STEP 2 : Clip the three support bars in between the two hoops.

STEP 3 : Place the netting over the cage, bury ends down and peg down.

STEP 4 : Use pipe clips provided to secure the netting to the tubing.

