

PEA & BEAN DOMED FRAME (W) 750MM X (L) 2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

5	ALUMINIUM TUBING 19MM X 2M
4	ALUMINIUM TUBING 19MM X 1.2M
2	ALUMINIUM TUBING 19MM X 750MM
6	LARGE JOINER 19MM DOOR UPRIGHT TUBE CLIP
2	HIGH TOP HOOP - SMALL - SINGLE
4	LARGE JOINER TEE
1	COVER
30	19MM CLIPS
16	STEEL PEGS

ASSEMBLY PROCESS (BASE)

STEP 1 : Take 2 of the 2m poles and 2 of the 750mm poles and lay them out in a rectangle.

STEP 2 : Connect the 4 joiners at both ends.

STEP 3 : Insert 4 of the 1.2m x 19mm poles (legs) into the joiners and then push them into the soil roughly 30cm.
This gives you the base.

STEP 4 : Place the hoops on top of the joiners and push in.

ASSEMBLY PROCESS (CLOCHE SUPPORT BAR)

STEP 1 : Insert 2 x joiner upright tube clips into both ends of the 3 remaining 2m poles, this creates the support bar.

STEP 2 : Clip the three support bars in between the two hoops.

STEP 3 : Place the netting over the cage, bury ends down and peg down.

STEP 4 : Use pipe clips provided to secure the netting to the tubing.

