

STANDARD CAGE

(H) 0.5M X (W) 1.2M X (L) 5.4M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

| | |
|---|---|
| 4 | 13MM X 600MM ALUMINIUM TUBE |
| 4 | 13MM X 600MM ALUMINIUM EXTENSION TUBE |
| 6 | 13MM X 900MM ALUMINIUM TUBE |
| 6 | 13MM X 900MM ALUMINIUM EXTENSION TUBE |
| 8 | 16MM UPRIGHTS |
| 4 | JOINER CORNER & 4 TEES (OR 8 BUILD A BALLS) |

IF ORDERED WITH COVER

| | |
|----|------------|
| 1 | COVER |
| 26 | STEEL PEGS |
| 16 | 13MM CLIPS |
| 16 | 16MM CLIPS |

| HEIGHT TABLE | | |
|----------------|----------------|----------------|
| ERECTED HEIGHT | UPRIGHT HEIGHT | PUSH INTO SOIL |
| 1.2M | 1.5M | 300MM |
| 900MM | 1.2M | 300MM |
| 700MM | 900MM | 200MM |
| 500MM | 600MM | 100MM |

ASSEMBLY PROCESS

STEP 1: The legs are made up of the larger tubes (16mm). Push a build a ball or joiner onto each one (refer to the cage diagram).

STEP 2: Connect the 600mm + 600mm extension pole to create the 1.2m width bars.

STEP 3: Connect the 900mm + 900mm extension tube to create the 1.8m length bars. Connect the 1.8m + 1.8m + 1.8m tubes together with 2 tee joiners between them to create the 5.4m length bars.

STEP 4: Push the legs (16mm uprights) into the ground to create your erected height (refer to the height table).

STEP 5: Lay cover (if ordered) over the frame and secure using the 16mm clips on each leg, and equally spacing the 13mm clips on the crossbars. Bury the ends of the cover and secure with pegs.

Please Note: If due heavy forecast of snow please remove the roof netting beforehand.)

