

DOMED ALUMINIUM HOOP FRAME

(H) 1.88M X (W) 1.2M X (L) 1.2M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	ALUMINIUM HOOP
4	ALUMINIUM TUBE 1.5M
5	ALUMINIUM TUBE 1.2M
4	JOINER TEE
2	UPRIGHT TUBE CLIP

1	COVER
18	BLACK HOOP CLIPS 19MM
16	STEEL PEGS

ASSEMBLY PROCESS BASE

STEP 1: Take 4 of the 1.2m tubes and lay them out in a square. Insert the joiners (tees) into the ends to create a sturdy frame.

STEP 2: Insert the hoops on both sides of the square frame.

STEP 3: Insert the 4 x 1.5m poles into the bottom of the (tees) to create the legs and push into the ground 300mm to get a 1.2m erected height.

STEP 4: Use the upright tube clips in both ends of the last 1.2m poles to create a support bar which connects both hoops together.

STEP 5: Place the cover over the top of the cage leaving equal netting down either side. Pull the netting taught and use the steel pegs to peg the netting down into the soil. Use the pipe clips provided to fasten the netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

(Please note) if due heavy forecast of snow please remove the cover beforehand.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

