

DOMED ALUMINIUM HOOP FRAME

(H) 1.88M X (W) 1.2M X (L) 2.4M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

3	ALUMINIUM HOOP
6	ALUMINIUM TUBE 1.5M
9	ALUMINIUM TUBE 1.2M
4	JOINER TEE
2	JOINER CROSS
4	UPRIGHT TUBE CLIP

1	COVER
18	BLACK HOOP CLIPS 19MM
10	STEEL PEGS

ASSEMBLY PROCESS BASE

STEP 1: Take 7 of the 1.2m tubes and lay them out in two squares side by side sharing the center pole. Insert the joiners (tees) into the four corners, and two crosses in the centre.

STEP 2: Insert the three hoops on each intersection of the frame.

STEP 3: Insert the 6 x 1.5m poles into the bottom of the joiners to create the 6 legs and push into the ground 300mm to get a 1.2m erected height.

STEP 4: Use the upright tube clips in both ends of the last 2x 1.2m poles to create support bars which connects all the hoops together.

STEP 5: Place the cover over the top of the cage leaving equal netting down either side. Pull the netting taught and use the steel pegs to peg the netting down into the soil. Use the pipe clips provided to fasten the netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

(Please note) if due heavy forecast of snow please remove the cover beforehand.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

