

DOMED ALUMINIUM HOOP FRAME (H) 1.88M X (W) 1.2M X (L) 3.6M

CONTENTS

4	ALUMINIUM HOOP
8	ALUMINIUM TUBE 1.5M
13	ALUMINIUM TUBE 1.2M
4	JOINER TEE
4	JOINER CROSS
6	UPRIGHT TUBE CLIP

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

ASSEMBLY PROCESS BASE

STEP 1: Take 10 of the 1.2m tubes and lay them out in three squares side by side sharing the center poles. Insert the joiners (tees) into the four corners, and four crosses in the centre.

STEP 2: Insert the four hoops on each intersection of the frame.

STEP 3: Insert the 8 x 1.5m poles into the bottom of the joiners to create the 8 legs and push into the ground 300mm to get a 1.2m erected height.

STEP 4: Use the upright tube clips in both ends of the last 3 1.2m poles to create support bars which connects all the hoops together.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

