

# SMALL ALUMINIUM HOOP FRAME (H) 1.46M X (W) 1.2M X (L) 6M

## CONTENTS

5	ALUMINIUM HOOP
10	ALUMINIUM HOOP EXTENSION 800MM
12	ALUMINIUM TUBE 1.5M
5	ALUMINIUM TUBE 1.2M
4	JOINER CORNER
6	JOINER TEE
8	UPRIGHT TUBE CLIP

## ASSEMBLY PROCESS

**STEP 1:** Take two of the 1.5m poles and lay them on the ground, then lay two of the 1.2m poles either side to create a rectangle. Repeat this four times to create four rectangles back to back.

**STEP 2:** Place the four corners on each corner making sure the joiner has a free slot pointing upwards. Place a tee joiner either side of the centre poles connecting the width poles to the length. Once again the tee joiners should have one slot free pointing upwards.

**STEP 3:** Insert the ten 800mm hoop extensions into the free slots in the joiner corners and tees. Then insert the round hoops into the extensions, this will complete the five hoops.

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

**STEP 4:** To assemble the four cloche support bars insert the upright tube clips into either end of the last four 1.5m tubes. Once assembled fixed lengthways between the hoops. Space equally apart with one support bar per hoop.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

