

SMALL HIGH TOP ALUMINIUM HOOP FRAME

(H) 1.56M X (W) 0.9M X (L) 1.5M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

2	ALUMINIUM HOOP
4	ALUMINIUM HOOP EXTENSION 800MM
3	ALUMINIUM TUBE 1.5M
2	ALUMINIUM TUBE 900MM
4	JOINER CORNER
2	UPRIGHT TUBE CLIP

ASSEMBLY PROCESS

STEP 1: Take 2 of the 0.9m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, connect each corner with a joiner to complete the rectangle.

STEP 2: Insert the 800mm extension poles into the upright slots of the corners.

STEP 3: Insert the hoop width ways into the top of the uprights, repeat this at both ends.

STEP 4: To create the support bar use the last 1.5m tube and insert the upright tube clips at either end. Once created, place this in the center of the hoops, one between each hoop.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

