

# SMALL HIGH TOP ALUMINIUM HOOP FRAME

(H) 1.56M X (W) 0.9M X (L) 4.5M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

4	ALUMINIUM HOOP
8	ALUMINIUM HOOP EXTENSION 800MM
9	ALUMINIUM TUBE 1.5M
4	ALUMINIUM TUBE 0.9M
4	JOINER CORNER
4	JOINER TEE
6	UPRIGHT TUBE CLIP

1	COVER
28	BLACK HOOP CLIPS 19MM
26	U PINS

## ASSEMBLY PROCESS

**STEP 1:** Take 2 of the 0.9m tubes and 2 of the 1.5m tubes and lay them on the ground into a rectangle, repeat this three times to create two three rectangles connecting to each other. Connect each corner with a joiner corner, and center poles with joiner tees.

**STEP 2:** Insert the 800mm extension poles into the upright slots of the corners and tees.

**STEP 3:** Insert the hoop width ways into the top of the uprights, repeat this four times.

**STEP 4:** To create the support bar use the last 1.5m tubes and insert the upright tube clips at either end. Once created, place this in the center of the hoops, once between each hoop.

**STEP 5:** Place the cover over the top of the cage leaving equal netting down either side. Pull the netting taught and use the steel pegs to peg into the soil. Use the pipe clips provided to fasten the netting to the tubing.

For a tight fit apply some pressure when fitting the clips and joiners into the aluminium. A mallet is usually required.

Please note: If due heavy forecast of snow please remove cover before hand.

This does not come with a door, you just need to remove a few clips and pegs to gain entrance from any side you wish.

