

# HIGHTOP ALUMINIUM HOOP FRAME

(H) 1.68M X (W) 0.8M X (L) 1.2M

**PLEASE NOTE:** A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

## CONTENTS

2	ALUMINIUM HOOP
7	ALUMINIUM TUBE 1.2M
2	ALUMINIUM TUBE 800MM
4	JOINER TEE
2	UPRIGHT TUBE CLIP

1	COVER
18	PIPE CLIPS
6	STEEL PEGS

## ASSEMBLY PROCESS BASE

**STEP 1:** Take 2x 1.2m length tubes and 2x 800mm width tubes and lay them out into a square on a flat surface and connect each corner with a tee joiner.

**STEP 2:** Insert a hoop onto each end of the frame making sure the joiners are fully submerged.

**STEP 3:** Connect the upright tube clips into each end of the 1.2m tube to create the support bar, you can then connect this between the two hoops.

**STEP 4:** (This part may require two people)  
Mark on the floor where the legs of the cage are going to go, then use a mallet and a piece of wood to sink

the poles into the ground to reach the advised erected height. You can then lift the top part of the cage and connect it on top of the legs.

**STEP 5:** Place the cover over the top of the cage leaving equal netting down either side. Pull the netting taught and use the steel pegs to peg the netting down into the soil. Use the pipe clips provided to fasten the netting to the tubing.

For a tight fit, some pressure is required when fitting the clips, and a mallet is recommended for submerging the joiners into the aluminium tubes.

(Please note) if due heavy forecast of snow please remove the cover beforehand.

