

SQUARE ALUMINIUM HOOP FRAME (H) 1.85M X (W) 1.2M X (L) 3.6M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

4	ALUMINIUM HOOP
24	ALUMINIUM TUBE 1.2M
4	JOINER TEE
4	JOINER CROSS
12	UPRIGHT TUBE CLIP

1	COVER
36	PIPE CLIPS
30	STEEL PEGS

ASSEMBLY PROCESS BASE

STEP 1: Take 10x 1.2m tubes and lay them out into three inter connecting squares on a flat surface and connect each corner with a tee joiner and four crosses in the middle.

STEP 2: Insert a hoop onto each end of the frame and two in the middle making sure the joiners are fully submerged.

STEP 3: Connect the upright tube clips into each end of 6x 1.2m tubes to create the support bars, you can then connect these between the hoops.

STEP 4: (This part may require two people)
Mark on the floor where the legs of the cage are going

to go, then use a mallet and a piece of wood to sink the poles into the ground to reach the erected height of 0.9m. You can then lift the top part of the cage and connect it on top of the legs.

STEP 5: Place the cover over the top of the cage leaving equal netting down either side. Pull the netting taught and use the steel pegs to peg the netting down into the soil. Use the pipe clips provided to fasten the netting to the tubing.

For a tight fit, some pressure is required when fitting the clips, and a mallet is recommended for submerging the joiners into the aluminium tubes.

(Please note) if due heavy forecast of snow please remove the cover beforehand.

