

STANDARD CAGE (W) 3.6M X (L) 3.96M

PLEASE NOTE: A mallet is usually required to tap the joiners into the tubes. Please ensure the joiners are fully submerged into the aluminium.

CONTENTS

6	13MM X 1.08M ALUMINIUM TUBE
6	13MM X 900MM ALUMINIUM TUBE
12	13MM X 900MM ALUMINIUM EXTENSION TUBE
9	16MM UPRIGHTS
4	JOINER CORNER & 4 TEES (OR 9 BUILD A BALLS)
1	JOINER CROSS

IF ORDERED WITH COVER

1	COVER
20	STEEL PEGS
20	13MM CLIPS
20	16MM CLIPS

HEIGHT TABLE		
ERECTED HEIGHT	UPRIGHT HEIGHT	PUSH INTO SOIL
1.2M	1.5M	300MM
900MM	1.2M	300MM
700MM	900MM	200MM
500MM	600MM	100MM

ASSEMBLY PROCESS

STEP 1: The legs are made up of the larger tubes (16mm). Push a build a ball or joiner onto each one. When laying out the legs make sure the cross joiner or build a ball is in the center. (Refer to the cage diagram).


STEP 2: Connect the 900mm + 900mm extension tube to create the 1.8m width bars. Connect the 1.8m + 1.8m width bars together with 1 tee joiner between them to create the 3.6m width bars.

STEP 3: Connect the 1.08m + 900mm extension tube to create the 1.98m length bars. Connect the 1.98m + 1.98m length bars together with 1 tee joiner between them to create the 3.96m length bars.

STEP 4: Connect each joiner tee to the center cross/crosses with the remaining tubes.

STEP 5: Push the legs (16mm uprights) into the ground to create your erected height (refer to the height table).

STEP 6: Lay cover (if ordered) over the frame and secure using the 16mm clips on each leg, and equally spacing the 13mm clips on the crossbars. Bury the ends of the cover and secure with pegs.



Please Note: If due heavy forecast of snow please remove the roof netting beforehand.)